




PRO-STEP™

Fitting Instruction



Issue 1

PRO-TM20-NT

Item	Qty	Description
A	1	PRO-TM20-NT STEP
B	2	Handed Side Arms
C	8	M12 x 110 Bolts & Nyloc Nuts
D	4	M12 x 35 Bolts & Nyloc Nuts
E	24	12 x 25 Flat Washers
F	8	Black M12 Bolt Caps

1. Using Item C with Item E fix Items B to each correct chassis member.
2. Using Item D with Item E loosely assembly the fixing through the forward upper mounting point only leaving the fixing loose enough to enable you to slide Item A through the open slot.
3. Using Item D with Item E fix Item A to Item B.
4. Fully tighten all fixings ensuring the Pro-Step is rigid, square and secure.

